

Autoclave test report

MicroIntensive™ L Cover

PRODUCT

MicroIntensive™ L Cover (TSU 162385)



TEST CONDITIONS

Autoclave

Varioklav 135 S, steam sterilizer, single pre-vacuum, usable volume 135 litres

Test Parameter

134°C for 5 minutes

Pre-vacuum: 20 kPa

Cooling-down of product between autoclaving cycles

RESULT

After 1 autoclaving cycle the MicroIntensive™ L Cover shows no damages and fulfills FHCS specification requirement.



Photo 1: MicroIntensive™ L Cover after 1 autoclaving cycle

ADDITIONAL COMMENTS

- This test was done in the laboratory of FHCS GmbH, Regional Technical Centre.
- The product was not used for cleaning between autoclaving cycles.
- Different conditions at the customer can lead to a different result.

Date: 2018/10/30